



Vinkli 2, Tartu  
51014, Estonia  
+372 5666 7699  
info@huum.eu

**huum.eu**  
#huumsauna

## WIRING INSTRUCTIONS

Sauna controller UKU extension box

## EXTENSION BOX 63 for HIVE Heaters 240V, 2x63A, 60Hz

Used with all controller models **UKU Wi-Fi**, **UKU GSM** and **UKU Local**. **This installation drawing replaces the installation drawing in UKU manual.**

The following scheme is used to connect the heater over 9 kW (Hive 12, 15 and 18 kW). Fix the unit to the wall with 4 screws.

### Placement

The extension box has to be located outside the steam room, near UKU main module.

Find the latest updates on our webpage [www.huum.eu](http://www.huum.eu)

